

Mini-Trek Battery Installation

Removing Old Batteries:

1. Unscrew lens and remove the LED module.
2. Remove the center battery.
3. Next, remove the battery that is noted as 2 (-) on the outer case. Using a ballpoint pen or similar instrument, press down on the edge of the battery and push the top of the battery toward the center of the chamber. Invert the flashlight body and tap on a hard surface and remove battery #2.
4. Repeat procedure with the last battery, noted at #1 (+) on the outer case.

Installing New Batteries:

1. Begin with the battery noted as #1 (+) on the outer case. With positive end up, insert the battery at an angle onto the spring at the bottom of the #1 slot. With the end of a ballpoint pen, press down on the top of the battery and move it into its slot, making sure the spring at the bottom of that slot is fully covered (see Fig. A). The center spring should still be visible.
2. Next replace the battery noted as 2 (-) on the outer case. With the negative end up, insert the battery at an angle onto the spring at the bottom of the #2 slot. Press down on the edge of the battery with a ballpoint pen and move it into its slot.
3. Place the last battery in the center position, with the positive end up. It is noted at 3 (+) on the outer case. This battery sits higher than the others and does not need to be pushed down.
4. Replace the LED module and screw the lens down. If light does not come on, check battery positions.

